Chapter 4 - MEANS OF EGRESS

Program Statement

Life safety codes generally require at least two exits on each floor. These exits should be located as far as possible one from the other.

To a considerable extent, the number and width of exits are determined by building occupancy. In high hazard occupancy, no part of a building should be farther than 75 feet from an exit. From medium and low hazard occupancy, this distance may be increased to 100 and 150 feet respectively.

- Building and structural materials used in the exits will not cause injury to the occupants of a building during emergency evacuations.

- An exit may be protected by separation. The construction materials of the separating walls will meet the following requirements:

  One-hour fire resistance rating when the exit connects three stories or less.

  Two-hour fire resistance rating when the exit connects four or more stories.

- Exits will be arranged and maintained as to provide unobstructed egress from all parts of the building at all times.

- Beside exit signs, direction signs indicating the exit route will be used when the exit path is not apparent.

- Any doorway not constituting an exit way that can be mistaken as such, will have the following a warning sign:

  "NOT AN EXIT"

- All exits will have adequate and reliable sources of illumination.

- Fire alarms will be provided in buildings where fire warnings of other type are not effective.

- In addition, fire safety codes may require smoke alarms and automatic fire extinguishing systems.

APPENDIX A
GLOSSARY OF TERMS

Emergency action plan

A plan describing how employees will respond to different types of emergencies, taking into account the specific worksite layout, structural features, and emergency systems.

Exit

The portion of a means of egress that is separated from all other spaces of the building or structure by construction or equipment. It provides a protected way of travel to the exit discharge.

Exit access

The portion of a means of egress that leads to an exit.

Exit discharge

The portion of a means of egress between the termination of an exit and a public way.

High hazard contents

Materials that are liable to burn with extreme rapidity and generate poisonous fumes or explosions in case of fire.

Low hazard contents

Materials of low combustibility so that no self-propagating fire can occur. Consequently, the only probable danger requiring the use of emergency exits will be from panic, fumes, or smoke, or fire from some external source.

Means of egress

A continuous and unobstructed way of exit travel from any point in a building or structure to a public way. It consists of three separate and distinct parts: the way of exit access, the exit, and the way of exit discharge.

Ordinary hazard contents

Materials that are liable to burn with moderate rapidity and generate a considerable volume of smoke but from which neither poisonous fumes nor explosions are to be feared in case of fire.